



778S

Quick Start Guide



Initial Set-up

Plug in the power cord. Switch on the mains power. Press the Standby button. Set the source to Streaming.



Ethernet Connection (Recommended)

Connect an Ethernet cable from your router to the 778S. Power on the device and select 'Streaming' mode. Wait for the Ethernet icon to appear on the OLED screen. Connect your Smart Phone or Tablet to the same router/network.

Wi-Fi Connection Options:


Via WPS

Press the WPS button on the back of the 778S. Press the WPS button on your router. Look for the Wi-Fi icon on the display when connected.


Tip: If not successful, try reversing the button sequence or repeat the steps.

Via Access Point (AP Mode)


Hold the 778S WPS button for 6 seconds until "AP Mode" shows on the display. On your Smart Phone or Tablet, connect to the 778S Wi-Fi network 778S-XXXX. Open the Mission 778S App, tap Wi-Fi Setup and Choose your home Wi-Fi > enter password > press OK. The Wi-Fi icon on the 778S OLED screen will confirm connection.




Click Wi-Fi Setup



Pick your Wi-Fi




Entering Password



Click Control

Streaming

In the app, tap 'Control' when your device appears, enable services and select the source via the sidebar:



Please download and install the Mission 778S app from the Apple App Store or Google Play Store by scanning the QR code.

